

# FLAT BACKS

Part No.	For digital/ dial indicators
7330-F1	2311
7330-F2	2301
	2302
	2308
	2309 (except 2309-30, 2309-30F)
	2313
	2314
	2315
7330-F4	2316
	2324
	2801
	2304
	2304
7330-F5	2103
	2104
	2108
	2109
	2112
	2115
	2137
	2117
	2118
	2138
	2139
	2501



7330-F2



7330-F8

Part No.	For digital/ dial indicators
7330-F6	2307
	2318
	2326
7330-F7	2830
	2837
	2882
	2885
	2888
	2889
	2891
2892	
7330-F8	2832
	2890
	2887
7330-F9	2886
7330-F10	2310

